



Expand QuickScreen 3 Set-up Instruction



ATTENTION: adjustable feet

- Remove banner stand from case.
 - Remove expandable pole from slot in base and open.
 - Turn foot in center of base to open position.
 - Place one end of pole in hook.
 - Place your foot on foot of base.
 - Raise banner to fully extended position.
 - Place other end of pole in hole on base.
 - Adjust foot of base.
- Note: Light clips on top of banner